

## Netcomm NB16DG Fibre configuration

### Logging into the gateway:

1. Ensure your device is connected to the Router (preferably via cable)
2. Open a web browser
3. Type the following in the address bar at the top: **192.168.20.1**
4. Default Username: **admin**
5. Default Password: **admin**
6. This should then give access to the routers user interface.\*  
\*\* (If the password is incorrect you will need to Factory Reset the router by pushing the Inset Reset button on the back for 10 seconds) \*\*

### How to add correct settings for the NOW network:

1. Select: **Manually set up connection**
2. At the bottom of the page select: **Switch to Advanced View**
3. From the top menu select: **Network Setup**
4. From the sub-menu select: **Network Setup**

On the following page set the following:

1. Wan Interface: **Ethernet WAN**
2. WAN Type: **PPP over Ethernet**
3. Username: **(your NOW account ID)@nownz.co.nz**
4. Password: **password**
5. Primary DNS: **202.137.240.39**
6. Secondary DNS: **202.137.240.40**
7. Service Name: **NowNZ**
8. Assigned IP address: **(Leave Blank)**
9. MTU: **0**
10. NAT: **Enable**
11. Multicast: **Disable**
12. IGMP Snooping: **Unticked**
13. VLAN Tagging: **Unticked**

You should now be connected to Fibre!

If your internet connection is still not working, give NOW Technical Support a call.



Status **Network Setup** Forwarding Rules Security Settings Advanced Settings Toolbox

Item	Setting
WAN Interface	Ethernet WAN <input checked="" type="radio"/> Active <input type="radio"/> Inactive
WAN Type	PPP over Ethernet
Username	(Your NOW ID)@nownz.co.nz
Password	password
Primary DNS	202.137.240.39
Secondary DNS	202.137.240.40
Service Name	NOW NZ (optional)
Assigned IP Address	(optional)
MTU	0 (0 is auto)
NAT	<input checked="" type="checkbox"/> Enable
Multicast	Disable
IGMP Snooping	<input type="checkbox"/> Enable
VLAN TAG	<input type="checkbox"/> Enable 0 (range: 1-4094)